


## POWER ON


Press the power key  until beep is heard.

## POWER OFF



Tap the power key briefly, the message below will display. Press [ENTER] to continue.




## STATUS BAR



## TOGGLE

Press  and then  to toggle to different application slot. Status bar will reflect the slot in the right corner.



## FORMATTING LETTERS

Press the number with the corresponding letter until the number changes to the correct letter.

Letters must be changed within a ½ second.









Example:

To form **J**, press **[5]** 2 times

To form **K**, press **[5]** 3 times

To form **j**, press **[5]** 5 times

## PHYSICAL KEYPAD

	Press the red key to cancel the current operation or return to the previous menu.
	Press the yellow key to clear an action or backspace clearing each character.
	Press the green key to signify to the terminal that the task is complete, or press to enable a function or perform an action based on inputted data.
	Press the feed key to advance the receipt.
	Press the up arrow to move up in the sub-menu. Press the up arrow in a text box to go to the beginning.
	Press the down arrow to move down the sub-menu. Press the down arrow in a text box to go to the end.
	Press the F1 to scroll to the left in a text box.
	Press the F2 to scroll to the right in a text box.

*SUB-MENU: Pressing the physical number key will shortcut to the function.*

## KEY FUNCTIONS

Use up arrow **[\*]** key and down arrow **[#]** key to highlight a menu item.

Press **[ENTER]** to select the currently highlighted menu item.

Press the number key corresponding to the menu item.

To exit out of a sub-menu, press **[CANCEL]**.

### **24 X 7 TECHNICAL SUPPORT**

866.392.8326 (option 4)

Email: [support@exadigm.com](mailto:support@exadigm.com)

Technical Support will confirm the terminal model and serial number